



รายการอะไหล่ REX NP50A

รุ่น	PART LOCATION	PART NO.	KT-CODE	REX CODE	DESCRIPTION
NP50A	1. BASE	29	R022-1080	N048	STRAINER
NP50A	5. CUTTER, REAMER	21	R022-1220	PM38	REAMER CONE
NP50A	4. CARRIAGE	2	R022-1470	PM55	OIL TUBE CONNECTOR
NP50A	1. BASE	18-A	R022-2650	MY20P	TOGGLE SWITCH
NP50A	3. MOTOR ASSEMBLY	5	R022-2652	PMM1H	STATOR ASSEMBLY
NP50A	2. MAIN SHAFT, MOTOR	27	R022-2655	1035	JOINT
NP50A	2. MAIN SHAFT, MOTOR	24	R022-2656	W07B	HEX SOCKET HEAD CAP SCREW
NP50A	2. MAIN SHAFT, MOTOR	13	R022-2660	PM07	REAR CHUCK COMPLETE SET
NP50A	3. MOTOR ASSEMBLY	19	R022-2665	PMM12	FINAL PINION GEAR
NP50A	5. CUTTER, REAMER	17	R022-2670	N025	REAMER ARM
NP50A	2. MAIN SHAFT, MOTOR	21	R022-2710	PMM10	CARBON BRUSH
NP50A	3. MOTOR ASSEMBLY	15	R022-2750	PMM50	ARMATURE ASSEMBLY
NP50A	2. MAIN SHAFT, MOTOR	17	R022-2850	PM30	GEAR PUMP WITH JOINT (1035)
NP50A	4. CARRIAGE	8	R022-2855	PM41	CARRIAGE HANDLE
NP50A	2. MAIN SHAFT, MOTOR	12	R022-2860	70KS	CHUCK JAW INSERT SET
NP50A	5. CUTTER, REAMER	7	R022-3290	5074	CUTTER ROLLER
NP50A	5. CUTTER, REAMER	13	R022-3320	2471	CUTTER PIN S
NP50A	5. CUTTER, REAMER	8	R022-3330	5079	CUTTER PIN L
NP50A	4. CARRIAGE	4		1076	CUTTER ARM STOP PIN
NP50A	4. CARRIAGE	15		1096	REAMER HOLDER STOP PIN
NP50A	5. CUTTER, REAMER	11		4067	CUTTER GUIDE
NP50A	5. CUTTER, REAMER	4		4072	CUTTER FRAME STOP PIN
NP50A	1. BASE	42		4081	EARTHED ADAPTER
NP50A	1. BASE	43		4082	CAPTYRE CORD SET
NP50A	5. CUTTER, REAMER	22		5096	SPRING
NP50A	5. CUTTER, REAMER	6		9025	SPRING
NP50A	5. CUTTER, REAMER	12		9027	CUTTER GUIDE PIN
NP50A	5. CUTTER, REAMER	5		135076	CUTTER WHEEL
NP50A	2. MAIN SHAFT, MOTOR	7		02NNC	MAIN SHAFT WITH GEAR
NP50A	1. BASE	31		0411-55	OIL LINE TUBE G (STRAINER)
NP50A	2. MAIN SHAFT, MOTOR	18		0411-550	OIL LINE TUBE G (INTAKE)
NP50A	2. MAIN SHAFT, MOTOR	25		0411-700	OIL LINE TUBE G (FEED)
NP50A	5. CUTTER, REAMER	10		0NCNTPS	CUTTER COMPLETE SET
NP50A	4. CARRIAGE	6		G861	STOPPER
NP50A	1. BASE	7		J009	GREASE NIPPLE
NP50A	2. MAIN SHAFT, MOTOR	23		N006	CHUCK COMPLETE SET
NP50A	5. CUTTER, REAMER	9		N023	CUTTER ARM
NP50A	5. CUTTER, REAMER	18		N027	REAMER SHAFT (WITH HAND GRIP)
NP50A	1. BASE	8		N054	CAP



รายการอะไหล่ REX NP50A

รุ่น	PART LOCATION	PART NO.	KT-CODE	REX CODE	DESCRIPTION
NP50A	2. MAIN SHAFT, MOTOR	11		N0CJS	CHUCK JAW SET WITH NO.12
NP50A	1. BASE	37		N121C	PIPE STAND W/ N125 LEG CAP
NP50A	1. BASE	38		N125C	LEG CAP
NP50A	4. CARRIAGE	10		N200	SECURITY COLLAR
NP50A	5. CUTTER, REAMER	3		N200	CUTTER FRAME
NP50A	1. BASE	15		N624	OIL PAN
NP50A	2. MAIN SHAFT, MOTOR	10		NH00	CHUCK BODY
NP50A	2. MAIN SHAFT, MOTOR	9		NS00	FRONT SCROLL
NP50A	5. CUTTER, REAMER	14		ONRTPS	REAMER COMPLETE SET
NP50A	4. CARRIAGE	7		PM03	CARRIAGE SUPPORT BAR A
NP50A	4. CARRIAGE	3		PM04	CARRIAGE SUPPORT BAR B
NP50A	2. MAIN SHAFT, MOTOR	8		PM06	HAND WHEEL
NP50A	2. MAIN SHAFT, MOTOR	6		PM08	REAR CHUCK COVER
NP50A	2. MAIN SHAFT, MOTOR	3		PM09	REAR CHUCK RECEPTACLE
NP50A	2. MAIN SHAFT, MOTOR	4		PM10	REAR SCROLL
NP50A	2. MAIN SHAFT, MOTOR	2		PM11	REAR CHUCK JAW
NP50A	1. BASE	11		PM13	SIDE COVER
NP50A	1. BASE	25		PM14	BOTTOM COVER
NP50A	1. BASE	14		PM16	SCRAP RECEIVER A
NP50A	1. BASE	51		PM1C	WARNING PLATE FOR EM SWITCH
NP50A	2. MAIN SHAFT, MOTOR	19		PM1H	MOTOR
NP50A	1. BASE	19-A		PM32	SWITCH ADAPTER PLATE
NP50A	1. BASE	18-B		PM35	ELECTROMAGNETIC SWITCH
NP50A	5. CUTTER, REAMER	1		PM43	CUTTER HANDLE WITH FEED SCREW
NP50A	1. BASE	21-A		PM44	NAME PLATE
NP50A	1. BASE	32		PM47	OIL TUBE COVER
NP50A	1. BASE	40		PM57	SWITCH HOLE COVER
NP50A	1. BASE	24-A		PM58	CAPTYRE CORD
NP50A	1. BASE	49		PM59	FOOT SWITCH WIRE
NP50A	1. BASE	9		PM60	BASE CASTING ASSEMBLY
NP50A	1. BASE	16		PM61	REAR COVER
NP50A	1. BASE	2		PM62	REAR GRIP
NP50A	1. BASE	6		PM64	PIPE SUPPORT STOPPER
NP50A	1. BASE	39		PM65	CABLE HOLE CAP
NP50A	1. BASE	22		PM73	CAUTION PLATE
NP50A	1. BASE	41		PM74	ON-OFF STICKER
NP50A	1. BASE	45		PM75	FWD-REV STICKER CE
NP50A	1. BASE	50		PM79	FOOT SWITCH
NP50A	4. CARRIAGE	5		PM88	CARRIAGE



รายการอะไหล่ REX NP50A

รุ่น	PART LOCATION	PART NO.	KT-CODE	REX CODE	DESCRIPTION
NP50A	2. MAIN SHAFT, MOTOR	31		PM91	FERRITE
NP50A	1. BASE	47-A		PM92	ELECTROMAGNETIC FILTER
NP50A	1. BASE	46-A		PM93	SURGE PROTECTION SWITCH
NP50A	1. BASE	17-A		PM94	CABLE GRAND
NP50A	1. BASE	35		PM96	SCRAP RECEIVER B
NP50A	1. BASE	5		PM97	MAIN SHAFT BEARING
NP50A	3. MOTOR ASSEMBLY	17		PMM03	GEAR CASING
NP50A	3. MOTOR ASSEMBLY	27		PMM04	GEAR COVER
NP50A	3. MOTOR ASSEMBLY	4		PMM07	MOTOR CASE
NP50A	3. MOTOR ASSEMBLY	6		PMM09	FAN CASING
NP50A	3. MOTOR ASSEMBLY	8		PMM10	CARBON CRUSH
NP50A	3. MOTOR ASSEMBLY	18		PMM11	FINAL GEAR
NP50A	3. MOTOR ASSEMBLY	20		PMM13	SPINDLE
NP50A	3. MOTOR ASSEMBLY	21		PMM14	PARALLEL KEY
NP50A	3. MOTOR ASSEMBLY	22		PMM15	BALL BEARING
NP50A	2. MAIN SHAFT, MOTOR	20		PMM16	CARBON BRUSH HOLDER
NP50A	3. MOTOR ASSEMBLY	9		PMM16	CARBON BRUSH HOLDER
NP50A	2. MAIN SHAFT, MOTOR	22		PMM17	CARBON BRUSH CAP
NP50A	3. MOTOR ASSEMBLY	7		PMM17	CARBON BRUSH CAP
NP50A	3. MOTOR ASSEMBLY	23		PMM1S	FINAL GEAR ASS'Y (#18-22)
NP50A	3. MOTOR ASSEMBLY	25		PMM2S	SECOND GEAR ASS'Y
NP50A	3. MOTOR ASSEMBLY	13		PMM31	BALL BEARING
NP50A	3. MOTOR ASSEMBLY	14		PMM32	DUST COLLAR
NP50A	3. MOTOR ASSEMBLY	26		PMM3S	FIRST GEAR ASS'Y
NP50A	3. MOTOR ASSEMBLY	10		PMM55	TAPPING SCREW
NP50A	3. MOTOR ASSEMBLY	12		PMM56	TAPPING SCREW
NP50A	3. MOTOR ASSEMBLY	24		PMM60	BALL BEARING
NP50A	3. MOTOR ASSEMBLY	1		PMM61	HEX SOCKET HEAD CAP SCREW
NP50A	3. MOTOR ASSEMBLY	2		PMM62	SPRING WASHER
NP50A	3. MOTOR ASSEMBLY	3		PMM63	WASHER
NP50A	3. MOTOR ASSEMBLY	16		PMM64	O-RING
NP50A	3. MOTOR ASSEMBLY	28		PMM65	PHILLIPS PAN SCREW
NP50A	3. MOTOR ASSEMBLY	11		PMMZ3	NAME PLATE
NP50A	1. BASE	34		PN37	NIPPLE
NP50A	4. CARRIAGE	9		PN38	SECURITY COLLAR SCREW
NP50A	1. BASE	3		W051	HEX SOCKET HEAD CAP SCREW
NP50A	2. MAIN SHAFT, MOTOR	1		W053	SOCKET HEAD CAP SCREW
NP50A	2. MAIN SHAFT, MOTOR	14		W067	HEX SOCKET HEAD CAP SCREW
NP50A	4. CARRIAGE	14		W06B	HEX SOCKET HEAD CAP SCREW



รายการอะไหล่ REX NP50A

รุ่น	PART LOCATION	PART NO.	KT-CODE	REX CODE	DESCRIPTION
NP50A	1. BASE	1		W083	HEX SOCKET HEAD CAP SCREW
NP50A	2. MAIN SHAFT, MOTOR	28		W08N	HEX SOCKET HEAD CAP SCREW
NP50A	1. BASE	20-A		W241	PAN HEAD MACHINE SCREW
NP50A	1. BASE	12		W252	PAN HEAD MACHINE SCREW
NP50A	1. BASE	44		W363	FLAT HEAD SCREW
NP50A	1. BASE	13		W781	HEX SOCKET SET SCREW
NP50A	1. BASE	10		W78F	HEX SOCKET HEAD SET SCREW
NP50A	1. BASE	27		WA42	DRAIN PLUG
NP50A	1. BASE	30		WA55	TAPPING SCREW
NP50A	1. BASE	36		WA68	WING BOLT (TYPE II)
NP50A	1. BASE	26		WA83	WING BOLT
NP50A	1. BASE	48		WC03	NUT
NP50A	2. MAIN SHAFT, MOTOR	15		WG06	SPRING WASHER
NP50A	2. MAIN SHAFT, MOTOR	29		WG08	SPRING WASHER
NP50A	4. CARRIAGE	12		WH18	WAVE WASHER
NP50A	2. MAIN SHAFT, MOTOR	16		WI61	FLAT WASHER
NP50A	2. MAIN SHAFT, MOTOR	30		WI81	FLAT WASHER
NP50A	4. CARRIAGE	13		WI87C	FLAT WASHER
NP50A	1. BASE	4		WL41	ROLL PIN
NP50A	4. CARRIAGE	11		WL54	ROLL PIN
NP50A	5. CUTTER, REAMER	20		WL76	ROLL PIN
NP50A	5. CUTTER, REAMER	16		WL87	ROLL PIN
NP50A	5. CUTTER, REAMER	19		WLA1	ROLL PIN
NP50A	5. CUTTER, REAMER	15		WLA2	ROLL PIN
NP50A	2. MAIN SHAFT, MOTOR	5		WM62	ROLL PIN
NP50A	5. CUTTER, REAMER	2		WN12	SPLIT PIN
NP50A	1. BASE	23		WN34	RIVET
NP50A	5. CUTTER, REAMER	23		WQ08	STEEL BALL
NP50A	1. BASE	33		WW16	SNAP RING
NP50A	1. BASE	28		ZJ50	PIPE BAND
NP50A	2. MAIN SHAFT, MOTOR	26		ZJ50	PIPE BAND
NP50A	4. CARRIAGE	1		ZJ50	PIPE BAND