

PARTS LIST

BC260T

CONTENTS


1. MAIN BODY	1 ~ 2
2. ENGINE	3 ~ 6
3. RECOIL STARTER	7 ~ 8
4. CARBURETOR, FUEL TANK	9 ~ 10
6. ACCESSORIES	11 ~ 12

2020. 05.




P/N 524996

1. BC260T
MAIN BODY




Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	366129	BC26T	1	
1-2	227831	Driveshaft Ass'y	1	
1-3	560699	Driveshaft Tube	1	
1-4	560385	Shaft Grip	1	
1-5	054691	Hanging Bracket Ass'y	1	Incl.6
1-6	089738	Bolt	1	M5x15
1-7	560094	Bracket Ass'y	1	Incl.8
1-8	560158	Bolt	6	M5x25
1-9	560700	Gearcase Ass'y	1	Incl.10-15
1-10	560504	Bolt	1	M6x8
1-11	560712	Cap Screw	1	M5x30
1-12	560722	Boss Adapter Ass'y	1	
1-13	560690	Blade Holder-B	1	
1-14	560150	Nut	1	M8
1-15	560716	Screw	1	M5x16
1-16	220549	Label	1	Caution
1-17	560751	Label	1	MARUYAMA BC260T
1-18	560202	Handle Ass'y-Left	1	
1-19	560203	Handle Ass'y-Right	1	
1-20	237533	Throttle Trigger Ass'y	1	Incl.21
1-21	560200	Label	1	
1-22	560176	Throttle Wire	1	
1-23	560224	Colgate Tube	1	135L
1-24	560229	Hanging Strap Ass'y	1	
1-25	560104	Safety Cover Ass'y	1	Incl.26
1-26	560158	Bolt	2	M5x25
1-27	227510	Mowing Blade	1	

2. BC260T
ENGINE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	875454	Engine	1	EE263TH/03
2-2	273153	Cylinder	1	
2-3	282330	Gasket	1	
2-4	261250	Cap Screw	4	M5x20
2-5	282579	Insulator	1	
2-6	267049	Gasket	1	
2-7	269826	Screw	2	M5x25
2-8	278560	Muffler Comp	1	
2-9	266264	Cap Screw	2	M5x50
2-10	282252	Gasket	1	
2-11	246083	Under Cover	1	
2-12	269827	Screw	1	M5x16
2-13	273154	Top Cover	1	
2-14	563151	Screw	1	M6x15
2-15	563099	Nut	1	M6
2-16	280144	Tapping Screw	1	
2-17	563680	Crankcase	1	
2-18	280488	Bearing	2	PPL 6001
2-19	563633	Oil Seal	1	
2-20	563632	Oil Seal	1	
2-21	563635	Snap Ring	1	H28
2-22	261612	Cap Screw	3	M5x30
2-23	273155	Piston	1	
2-24	261496	Piston Ring	2	(2)Required
2-25	261497	Piston Pin	1	
2-26	261037	Bearing,Needle	1	KBK8x11x11.8x1
2-27	261576	Clip,Piston	2	
2-28	277939	Crankshaft/Conn.Rod Ass'y	1	
2-29	269168	Clutch Ass'y	1	Incl.30,31
2-30	269169	Clutch Shoe	2	(2)required
2-31	269173	Spring, Clutch	1	
2-32	269647	Clutch Bolt	2	
2-33	269175	Washer	2	6.1x15x1.6
2-34	261777	Wave Washer	2	
2-35	563068	Fan Cover Ass'y	1	Incl.36-38
2-36	282214	Fan Cover	1	
2-37	289727	Clutch Drum	1	
2-38	563065	Snap Ring	1	#10
2-39	269831	Screw	4	M5x20
2-40	282215	Clip	1	
2-41	281169	Screw	1	M5x16
2-42	563535	Magneto Ass'y	1	Incl.43-49
2-43	277797	Rotor/Fan	1	
2-44	277798	Ignition Coil Ass'y	1	Incl.45-49
2-45	279577	Spark Plug Wire Ass'y	1	Incl.46,47

2. BC260T ENGINE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-46	278755	Plug Cap	1	
2-47	278756	Connector	1	
2-48	278754	Insulator	1	
2-49	278752	Cap	1	
2-50	261076	Woodruff Key	1	3x10
2-51	261417	Nut,Rotor	1	M8
2-52	280381	Spacer	2	
2-53	261256	Cap Screw	2	M4x25
2-54	285982	Spark Plug	1	NGK BPM8Y
2-55	269983	Stop Switch Ass'y	1	
2-56	563192	Label	1	

3. BC260T
RECOIL STARTER









Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	273093	Recoil Ass'y	1	Incl.2-12
3-2	280492	Reel	1	
3-3	287421	Spiral Spring	1	
3-4	280494	Screw	1	
3-5	280495	Starter Rope Ass'y	1	Incl.6-8
3-6	283616	Starter Rope	1	
3-7	280497	Starter Grip	1	
3-8	280550	Stopper	1	
3-9	280547	Washer	1	
3-10	280548	Collar	1	
3-11	269423	Nut	1	
3-12	288500	Plate	1	
3-13	287399	Stater Pulley Ass'y	1	
3-14	269833	Screw	1	M4x16
3-15	280489	Screw	2	M4x20
3-16	563695	Label	1	MARUYAMA

4. BC260T
 CARBURETOR, FUEL TANK



Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	273805	Carburetor Ass'y	1	Incl.2-15 New gasket required
4-2	281597	Pump Body	1	
4-3	262991	Purge Body	1	
4-4	262992	Cover Plate	1	
4-5	261874	Primer Bulb	1	
4-6	283905	Diaphragm, Meterring	1	
4-7	262993	Gasket	1	
4-8	262994	Diaphragm,Fuel Pump	1	
4-9	282576	Gasket	1	
4-10	289396	Main Jet	1	
4-11	261871	O-Ring	1	
4-12	261876	E-Ring	1	
4-13	261658	Swivel	1	
4-14	264682	Screw	2	
4-15	262996	Screw	4	
4-16	261864	Gasket	1	
4-17	264691	O-Ring	1	
4-18	563356	Air Cleaner Ass'y	1	Incl.19-21
4-19	266433	Housing	1	
4-20	264695	Filter	1	
4-21	277554	Cover	1	
4-22	269834	Screw	2	
4-23	563400	Fuel Tank Ass'y	1	Incl.24-34
4-24	563101	Fuel Tank	1	
4-25	275306	Fuel Tank Cap Ass'y	1	Incl.26
4-26	274875	Gasket	1	
4-27	563262	Breather Ass'y	1	
4-28	563232	Fuel Pipe Pick-up Ass'y	1	Incl.29-34
4-29	563233	Fuel Pipe Ass'y	1	Incl.30-32
4-30	288192	Grommet	1	
4-31	261690	Fuel Pipe	1	160L
4-32	288194	Return Pipe	1	3x6x85
4-33	277887	Filter Ass'y	1	
4-34	563014	Clip	1	
4-35	269828	Screw	2	M5x16
4-36	281208	Screw	1	M5x16
4-37	563014	Clip	1	

5. BC260T
ACCESSORIES



Ref. No.	Part No.	Part Name	Q'ty	Remarks
5-1	220534	Blade Cover	1	
5-2	210418	Box Spanner	1	13x19x(+)
5-3	219432	Wrench	1	4mm
5-4	022865	Double-ended Wrench	1	8x10
5-5	022540	Fuel Blending Bottle	1	
5-6	560749	Instruction Manual	1	BC200T/260T